

6600 Z-Stool Backrest installation

1. Carefully remove tube closures that are located on top of each side frame of the stool. This should be done by gently inserting a screwdriver into the notch on the bottom of the tube closure and carefully prying upwards. See ill A.
2. Remove backrest from carton and begin installation by aligning metal tubes that protrude from the backrest with the opening of the stool frames. See Ill. B.
3. Simultaneously insert both ends of the backrest tubes into the stool opening. Gently push until backrest tubes are flush with stool. Be careful to keep fingers clear of the connection area.
4. Using the provided knob-screws, insert them in the screw holes that are located just below the seat on each side of the stool. Make sure to tighten well. See ill. C.

Backrest removal

1. Remove knob-screws from frame.
2. The backrests are built to fit very tightly into the stool frame and some resistance may be encountered while attempting to remove. For easiest removal the following is recommended. Stand behind the stool and place hands at the bottom of the tubes on each side. Lift the tubes by pulling outward and upward at the same time. See Ill. D.

